

Braunschweig und Berlin



(1) EC-TYPE-EXAMINATION CERTIFICATE

(Translation)

- (2) Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres **Directive 94/9/EC**
- (3) EC-type-examination Certificate Number:



(4) Equipment: SN-sensors, types NJ... and SJ...

(5) Manufacturer: Pepperl + Fuchs GmbH

(6) Address: D-68307 Mannheim

- (7) This equipment and any acceptable variation thereto are specified in the schedule to this certificate and the documents therein referred to.
- (8) The Physikalisch-Technische Bundesanstalt, notified body No. 0102 in accordance with Article 9 of the Council Directive 94/9/EC of 23 March 1994, certifies that this equipment has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment and protective systems intended for use in potentially explosive atmospheres, given in Annex II to the Directive.

The examination and test results are recorded in the confidential report PTB Ex 00-29268.

(9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:

EN 50014:1997

(10) If the sign "X" is placed after the certificate number, it indicates that the equipment is subject to special conditions for safe use specified in the schedule to this certificate.

EN 50020:1994

- (11) This EC-type-examination Certificate relates only to the design and construction of the specified equipment in accordance with Directive 94/9/EC. Further requirements of this Directive apply to the manufacture and supply of this equipment.
- (12) The marking of the equipment shall include the following:

⟨Ex⟩ II 2 G EEx ia IIC T6

Zertifizierungsstelte Explosionsschutz By order: Braunschweig, October 05, 2000

Dr.-Ing. U. Johannsmeyer

Regierungsdirektor

sheet 1/4



Braunschweig und Berlin

SCHEDULE

(14) EC-TYPE-EXAMINATION CERTIFICATE PTB 00 ATEX 2049 X

(15) Description of equipment

The SN-sensors, types NJ... and SJ... are used to convert displacements into electrical signals.

The SN-sensors, types NJ... and SJ... may be operated with intrinsically safe circuits certified for categories and explosion groups [EEx ia] IIC or IIB resp. [EEx ib] IIC or IIB. The category as well as the explosion group of the SN-sensors depends on the connected supplying intrinsically safe circuit.

Electrical data

Evaluation and

supply circuit......type of protection Intrinsic Safety EEx ia IIC/IIB

resp. EEx ib IIC/IIB

only for connection to certified intrinsically safe circuits maximum values:

type 1	type 2	type 3	type 4
U _i = 16 V	U _i = 16 V	U _i = 16 V	U _i = 16 V
I _i = 25 mA	I _i = 25 mA	l _i = 52 mA	I _i = 76 mA
$P_i = 34 \text{ mW}$	$P_i = 64 \text{ mW}$	P _i = 169 mW	$P_i = 242 \text{ mW}$

The assignment of the type of the connected circuit to the maximum permissible ambient temperature and the temperature class as well as the effective internal reactances for the individual types of SN-sensors is shown in the following table:

sheet 2/4



Braunschweig und Berlin

SCHEDULE TO EC-TYPE-EXAMINATION CERTIFICATE PTB 00 ATEX 2049 X

			type 1 type 2							type 3	,	type 4		
types	Ci	Ľ	maximum permissible ambient temperature in °C for application in temperature class										in	
	[nF]	[µH]	Т6	T5	T4- T1	Т6	T5	T4- T1	Т6	T5	T4- T1	Т6	T5	T4- T1
NJ 2-11-SN	50	150	73	88	100	66	81	100	45	60	89	30	45	74
NJ 2-11-SN-G	50	150	76	91	100	73	88	100	62	77	81	54	63	63
NJ 2-12GK-SN	50	150	73	88	100	69	84	100	51	66	80	39	54	61
NJ 3-18GK-S1N	70	200	73	88	100	69	84	100	51	66	80	39	54	61
NJ 4-12GK-SN	70	150	73	88	100	69	84	100	51	66	80	39	54	61
NJ 5-18GK-SN	120	200	73	88	100	69	84	100	51	66	80	39	54	61
NJ 5-30GK-S1N	100	200	73	88	100	69	84	100	51	66	80	39	54	61
NJ 6-22-SN	110	150	73	88	100	69	84	100	51	66	80	39	54	61
NJ 6-22-SN-G	110	150	76	91	100	73	88	100	62	77	81	54	63	63
NJ 6S1+U.+N	180	150	73	88	100	69	84	100	51	66	80	39	54	61
NJ 8-18GK-SN	120	200	73	88	100	69	84	100	51	66	80	39	54	61
NJ 10-30GK-SN	120	150	73	88	100	69	84	100	51	66	80	39	54	61
NJ 15-30GK-SN	120	180	73	88	100	69	84	100	51	66	80	39	54	61
NJ 15S-UN	180	150	73	88	100	66	81	100	45	60	89	30	45	74
NJ 20S-UN	200	150	73	88	100	66	81	100	45	60	89	30	45	74
NJ 40-FP-SN	370	300	73	88	100	66	81	100	45	60	89	30	45	74
SJ 2-SN	30	100	73	88	100	66	81	100	45	60	78	30	45	57
SJ 2-S1N	30	100	73	88	100	66	81	100	45	60	78	30	45	57
SJ 3,5-S1N	30	100	73	88	100	66	81	100	45	60	89	30	45	74
SJ 3,5-SN	30	100	73	88	100	66	81	100	45	60	89	30	45	74

(16) Test report PTB Ex 00-29268

(17) Special conditions for safe use

- 1. For the application within a temperature range of -60 °C to -20 °C the SN-sensors, types NJ... and SJ... must be protected against damage due to impact by mounting into an additional housing.
- 2. The connection facilities of the SN-sensors, types NJ... and SJ... shall be installed as such that at least a degree of protection of IP20 according to IEC-publication 60529:1989 is met.
- 3. The assignment of the type of the connected circuit to the maximum permissible ambient temperature and the temperature class as well as the effective internal reactances for the individual types of SN-sensors is shown in the table given under item (15) of this EC-type-examination certificate.

sheet 3/4



Braunschweig und Berlin

SCHEDULE TO EC-TYPE-EXAMINATION CERTIFICATE PTB 00 ATEX 2049 X

4. With the application in group IIC inadmissible electrostatic charge of the plastic housing has to be avoided for following types of SN-sensors (warning label on the device).:

NJ 40-FP-SN...

5. Inadmissible electrostatic charge of parts of the metal houising has to be avoided for the following types of SN-sensors. Dangerous electrostatic charges of parts of the metal housing can be avoided by grounding of these parts whereas very small parts of the metal housing (e.g. screws) don't need to be grounded:

NJ 2-11-SN-G... NJ 6-22-SN-G... NJ 6S1+U3+N... NJ 6S1+U4+N... NJ 15S+U3+N... NJ 20S+U4+N... NJ 20S+U4+N... NJ 40-FP-SN-P3... NJ 40-FP-SN-P4...

(18) Essential health and safety requirements

Met by the standards mentioned above

Zertifizierungsstelle Explosionsschutz

By order:

Dr.-Ing. U. Johannsmey Regierungsdirektor

Braunschweig, October 05, 2000

sheet 4/4



Braunschweig und Berlin

1. SUPPLEMENT

according to Directive 94/9/EC Annex III.6

to EC-TYPE-EXAMINATION CERTIFICATE PTB 00 ATEX 2049 X

(Translation)

Equipment:

SN-sensors, types NJ... and SJ...

Marking:

⟨Ex⟩ II 2 G EEx ia IIC T6

Manufacturer: Pepperl + Fuchs GmbH

Address:

Königsberger Allee 87, 68307 Mannheim, Germany

Description of supplements and modifications

The SN-sensors of type series NJ... and SJ... listed below may in future also be used in hazardous areas where equipment of catagory-1 is required.

The modifications exclusively concern the "Electrical data" (change of maximum permissible ambient temperatures for application as category-1 equipment, reduction of the intrinsically safe evaluation and supply circuit to category ia) as well as the marking of the SN-sensors listed below.

NJ 2-11-SN	NJ 5-30GK-S1N	NJ 15-30GK-SN
NJ 2-11-SN-G	NJ 6-22-SN	NJ 15S-UN
NJ 2-12GK-SN	NJ 6-22-SN-G	NJ 20S-UN
NJ 3-18GK-S1N	NJ 6S1+U.+N	SJ 2-SN
NJ 4-12GK-SN	NJ 8-18GK-SN	SJ 2-S1N
NJ 5-18GK-SN	NJ 10-30GK-SN	SJ 3,5-S1N
		SJ 3.5-SN

For application as category-1 equipment the marking of the slot-type initiators listed above will be in the future:



The "Special conditions" are also valid for application as category-1 equipment without changes.

Sheet 1/3



Braunschweig und Berlin

1. SUPPLEMENT TO EC-TYPE-EXAMINATION CERTIFICATE PTB 00 ATEX 2049 X

Electrical data

Evaluation and supply circuit

type of protection Intrinsic Safety EEx ia IIC/IIB only for connection to certified intrinsically safe circuits Maximum values:

type 1	type 2	type 3	type 4
U _i = 16 V	U _i = 16 V	U _i = 16 V	U _i = 16 V
$I_i = 25 \text{ mA}$	I _i = 25 mA	I _i = 52 mA	$I_i = 76 \text{ mA}$
$P_i = 34 \text{ mW}$	P _i = 64 mW	P _i = 169 mW	$P_i = 242 \text{ mW}$

The assignment of the type of the connected circuit to the maximum permissible ambient temperature and the temperature class as well as the effective internal reactances for the individual types of slot-type intiators are shown in the following table:

				type 1		type 2		type 3			type 4			
types	C _i	Li	maximum permissible ambient temperature in °C for application in temperature class										in	
	[nF]	[µH]	T6	T5	T4- T1	Т6	T5	T4- T1	T6	T5	T4- T1	T6	T5	T4- T1
NJ 2-11-SN	50	150	56	68	96	49	61	89	28	40	68	13	25	53
NJ 2-11-SN-G	50	150	59	71	99	56	68	96	45	57	81	37	49	63
NJ 2-12GK-SN	50	150	57	69	97	52	64	92	34	46	74	22	34	61
NJ 3-18GK-S1N	70	200	57	69	97	52	64	92	34	46	74	22	34	61
NJ 4-12GK-SN	70	150	57	69	97	52	64	92	34	46	74	22	34	61
NJ 5-18GK-SN	120	200	57	69	97	52	64	92	34	46	74	22	34	61
NJ 5-30GK-S1N	100	200	57	69	97	52	64	92	34	46	74	22	34	61
NJ 6-22-SN	110	150	57	69	97	52	64	92	34	46	74	22	34	61
NJ 6-22-SN-G	110	150	59	71	99	56	68	96	45	57	81	37	49	63
NJ 6S1+U.+N	180	150	57	69	97	52	64	92	34	46	74	22	34	61
NJ 8-18GK-SN	120	200	57	69	97	52	64	92	34	46	74	22	34	61
NJ 10-30GK-SN	120	150	57	69	97	52	64	92	34	46	74	22	34	61
NJ 15-30GK-SN	120	180	57	69	97	52	64	92	34	46	74	22	34	61
NJ 15S-UN	180	150	56	68	96	49	61	89	28	40	68	13	25	53
NJ 20S-UN	200	150	56	68	96	49	61	89	28	40	68	13	25	53
SJ 2-SN	30	100	56	68	96	49	61	89	28	40	68	13	25	53
SJ 2-S1N	30	100	56	68	96	49	61	89	28	40	68	13	25	53
SJ 3,5-S1N	30	100	56	68	96	49	61	89	28	40	68	13	25	53
SJ 3,5-SN	30	100	56	68	96	49	61	89	28	40	68	13	25	53

Sheet 2/3



Braunschweig und Berlin

1. SUPPLEMENT TO EC-TYPE-EXAMINATION CERTIFICATE PTB 00 ATEX 2049 X

Test report: PTB Ex 03-23134

Zertifizierungsstelle Explosionsschutz

By order:

Dr.-Ing. U. Johannsmeyer

Regierungsdirektor,

Braunschweig, October 29, 2003